

LUFTOMAT

SELF - SERVICE MACHINE FOR INFLATING
AND DEFLATING THE INFLATABLE EQUIPMENT
(MATTRESSES, BOATS AND OTHER
SIMILAR EQUIPMENT).

CONTACT:

ABSOLUTE d.o.o.
luftomat@absolute.hr
www.luftomat.hr
www.absolute.hr
01 / 34 57 526





luftomat



LUFTOMAT is self-used by user. If following instructions on the machine, it is handled in a simple way. How to handle the machine is shown in the images on the machine itself. The instructions are written on four languages: croatian, english, german and italian.

An air blower is connected to the hose which has inflatable extensions. They can be adjusted to the slot in equipment. Users can inflate equipment immediately before using it or blow it out after use.

LUFTOMAT makes it easier to use inflated equipment.



LUFTOMAT starts by inserting coins in the slot and selecting the appropriate function (inflating and deflating equipment). How much credit you have, depending on the amount of the payment, you can see on the screen. According to customer's request, it is possible to embed card reader or Rfid tag. The machine can be connected to an Internet. In that way you can track how it operates.

LUFTOMAT (H 1200, W 650, D 500) is mounted on the base with four bolts. For installation and connection of the machine, you need to provide dimension area, sized 650 x 500 mm, grid leak and connector cable 2 x 1,5 mm².

THE RETURN OF INVESTMENT IS POSSIBLE IN 12 MONTHS!

MAKE YOUR BEACH MORE ATTRACTIVE!

